


AMGO  [®] **Hydraulics**

Original

Installation And Service Manual



TWO POST LIFT
Model: OHX-10/OHX-10H

CONTENTS


Product Features and Specifications	1
Installation Requirement	5
Steps of Installation	6
Exploded View	32
Test Run	40
Operation Instruction	41
Maintenance	42
Trouble Shooting	43
Lift disposal	43

I. PRODUCT FEATURES AND SPECIFICATIONS

CLEAR-FLOOR DIRECT-DRIVED MODEL FEATURES

Model OHX-10 (See Fig. 1)

- Direct-driven design, minimize the lift wear parts and breakdown ratio
- Dual hydraulic cylinders, designed and made as USA standards, utilizing oil seal in cylinder
- Self-lubricating UHMW Polyethylene sliders and bronze bush
- Single-point safety release, and dual safety design
- Clear-floor design, provide unobstructed floor space
- Overhead safety shut-off device prevents vehicle damages
- Stackable rubber pads



SPECIFICATIONS

Model	Lifting Capacity	Lifting Time	Lifting Height	Overall Height	Overall Width	Minimum Pad Height	Motor
OHX-10	10000lbs	57S	71-1/2"~80-1/2"	144"	135"	3-1/2"~12-1/2"	2.0HP

Model OHX-10H (See Fig. 2)

- Direct-driven design, minimize the lift wear parts and breakdown ratio
- Dual hydraulic cylinders, designed and made as USA standards, utilizing oil seal in cylinder
- Self-lubricating UHMW Polyethylene sliders and bronze bush
- Single-point safety release, and dual safety design
- Clear-floor design, provide unobstructed floor space
- Overhead safety shut-off device prevents vehicle damage
- Stackable rubber pads
- Adjustable column height

CAUTION
 DO NOT EXTEND LIFT ARMS
 PAST EDGE OF COLUMN.
 POWER UNIT RESERVOIR
 DAMAGE MAY OCCUR
 WHEN TOP OF ARM CONTACTS
 BOTTOM OF RESERVOIR.

**Please read carefully
 before operation!**




Fig. 2

SPECIFICATIONS

Model	Lifting Capacity	Lifting Time	Lifting Height	Overall Height	Overall Width	Minimum Pad Height	Motor
OHX-10H	10000lbs	63s	78-1/2"~87-1/2"	157"/168"	135"	3-1/2"~12-1/2"	2. OHP




Fig. 3

Swing and extending the arms to the lifting point of vehicle




Fig. 4

II. INSTALLATION REQUIREMENT

A. TOOLS REQUIRED

- ✓ Rotary Hammer Drill ($\Phi 3/4$)



- ✓ Hammer



- ✓ Level Bar



- ✓ English Spanner (12")



- ✓ Ratchet Spanner with Socket (28#)



- ✓ Wrench set
(10#, 13#, 14#, 15#, 17#, 19#, 24#, 27#)



- ✓ Pliers



- ✓ Socket Head Wrench (6#)



- ✓ Lock Wrench



Fig. 5

- ✓ Carpenter's Chalk



- ✓ Screw Sets



- ✓ Tape Measure (7.5m)



B. SPECIFICATIONS OF CONCRETE (See Fig. 6)

Specifications of concrete must be adhered to the specification as following.
Failure to do so may result in lift and/or vehicle falling.

1. Concrete must be thickness 6" minimum and without reinforcing steel bars, and must be dried completely before the installation.
2. Concrete must be in good condition and must be of test strength 3,000psi minimum.
3. Floors must be level without cracks.




Fig. 6

C. POWER SUPPLY

The electrical source must be 2.0HP minimum. The source cable size must be 2.5mm² and in good condition of contacting with floor.

III. STEPS OF INSTALLATION

A. Location of Installation

Check and insure the installation location (concrete, layout, space size etc.) is suitable for lift installation.

B. Use a carpenter's chalk line to establish installation layout of base-plate (See Fig.7).




Fig. 7

C. Check the parts before assembly.

1. Packaged lift and hydraulic power unit (See Fig. 8).



Fig. 8

2. Move aside the lift with fork lift or hoist, and open the extension packing carefully, take off the lifting arms and parts box from upper and inside the column, then move them to location nearby installation site, check the parts according to the shipment parts list (See Fig.9).




Fig. 9

3. Loose the screws of the upper package stand, take off the upper extension columns, take out the parts in the inner column and remove the package stand
4. Move aside the parts and check the parts according to the shipment parts list (See Fig.10, 11, 12).





Fig. 10



Part box① (87)
Fig. 11



Part box② (88)
Fig. 12


5. Open the bag 1 of parts and check the parts according to parts box list (See Fig. 13,14).




OHX-10
Accessories

Fig. 13







6. Open the bag 2 of parts and check the parts according to parts bag list (See Fig. 15).



D. Place the two columns in parallel on the ground of installation position, and determine the installation position of the power side column according to the condition of the installation site. Under normal circumstances, the power side column is installed on the right side of the entering direction; then install the oil hose.



E. Install the cylinder and connect the oil hose to the cylinder.



Install cylinder fitting and oil hose




Fig. 17




After connection

F. Mounting column Accessories.


a. OHX-10 Mounting column Accessories. Fig 18, Fig 19.




A side
Non-power side column
Fig. 18





B side
power side column
Fig. 19




C Magnified view



b. OHX-10H Mounting column Accessories. Fig. 20.



Place the two columns in parallel on the ground of the installation position, and determine the installation position of the power side column according to the condition of the installation site. Under normal circumstances, the power side column is installed on the right side of the entering direction; when installing the outer column, it should be installed according to the height of the workshop. When the height is not more than 168", the outer column is selected to install the lower position; when the height is greater than 168", the outer column can be installed with the high position.



Outer column low setting


Fig. 21

Outer column high setting


G. vertical leveling of columns (See Fig. 22)

a. OHX-10


Put the columns on the installation layout of base-plate, install the anchor bolts. Check the Columns plumpness with level bar, and adjusting with the shims if the columns are not vertical. Do not tighten the Anchor Bolts.




*Note: The anchor bolt is knocked into the ground at least 3-1/2".



Drilling



Cleaning



Bolting

b. OHX-10H

Put the columns on the installation layout of base-plate, install the anchor bolts. Check the Columns plumpness with level bar, and adjusting with the shims if the columns are not vertical. Do not tighten the Anchor Bolts. (See Fig. 23)





Fig. 23

*Note: The anchor bolt is knocked into the ground at least 3-1/2".



H. Install overhead top beam

(See Fig. 24).




Fig. 24

I. Installing the limit switch control bar and limit switch (See Fig. 25).




Fig. 25

I. Lift the carriages up and make them be locked at the same level (See Fig. 26).




Fig. 26

K. Install cables

K-1. OHX-10 cable connection

Cables pass through the bottom of the carriages and be pulled out from the square hole of carriages, then screw the two cable nuts (**See Fig. 27**)




Fig. 27

K-2. OHX-10H Low setting cable connection (See Fig. 28)

Note: the cable should go inside the carriage.




Fig. 28

K-3. OHX-10H High setting cable connection

Cables pass through the bottom of the carriages and be pulled out from the square hole of carriages, then screw the two cable nuts (See Fig. 29).




Fig. 29

L. Install oil hose and fitting

L-1. OHX-10 (See Fig. 30).




Fig. 30

L-2. OHX-10H Oil hose Installation (See Fig. 31).







Fig. 31

M. Install safety cable (See Fig. 32)



A side




B side

Fig. 32

M-1. Note: Requirements and instructions for installation of oil hose and safety lock wire cable.

1. Install Oil Hose (both sides and safety lock).

Note: Don't cross the oil hose and safety cable (See Fig. 33, 34 & 35).



**Power side Safety Device
Fig. 33**

**Off side Safety Device
Fig. 34**




Fig.35

N. Install lifting arms and adjust the arm locks.

N-1. Install the lifting arms (See Fig. 36), lowering the carriages down to the lowest position, then use the 8# socket head wrench to loosen the socket bolt (See Fig. 37). Adjust the arm lock as direction of arrow (See Fig. 38), Adjust moon gear and arm lock to make it to be meshed, then tighten the socket bolts of arm lock (See Fig. 39).





Fig. 36


Snap Ring



Loosen the Bolt


Use the 8# Socket Head Wrench to loosen the Socket Bolt

Fig. 37



Moon Gear

Fig. 38



Locking the bolts after the moon gear and arm lock engaged well

Locking the bolt

Fig. 39

O. Tighten all the hydraulic fittings, and fill the reservoir with hydraulic oil.

Note: In consideration of Hydraulic Power Unit’s durability and keep the equipment running in the perfect condition, please use Hydraulic Oil 46#.

P. Install electrical system

Connect the power source on the data plate of power unit.

Note: 1. Install the limit switch well.

2. For the safety of operators, the power wiring must contact the floor well.

3. Pay attention to the direction of rotations when using three phase motors.

Single phase motor (See Fig. 40).

1. Connecting the two power supply wires (active wire **L** and neutral wire **N**) to terminals of AC contactor marked **L1, L2** respectively.
2. Connecting the two motor wires to terminals of AC contactor marked **T1, T2**.
3. Connecting **A2** to **L2** of AC contactor.
4. Terminal **4#** of control button is connected with terminals **A1** of AC contactor, Terminal **3#** of control button is connected with terminals **L1** of AC contactor.




Fig. 40

*** Optional width extension kits installation guide:
a-1. OHX-10: oil hose, top beam installation. (Figure 41)**




Fig. 41

a-2. OHX-10: cable connection

Cables pass through the bottom of the carriages and be pulled out from the square hole of carriages, then screw the two cable nuts (See Fig. 42).





Fig. 42

Optional parts list

item	Part#	Description	OHX-10
			QTY
1	1102562008	Control connecting pin assy.	2
2	1002561009	Cable assy. $\phi 9.52 \times 9760\text{mm}$	2
3	1002571011	Oil hose assy. 5/16" 140mm (2 straight)	1
4	10620079	Straight fitting	1

b-1. OHX-10H: oil hose, top beam installation. (Figure 43)



b-2. OHX-10H: Cable connection. (fig. 44)

1. Low setting

Note: The cables should go inside the lifting carriage.




Fig. 44

2. High setting

Cables pass through the bottom of the carriages and be pulled out from the square hole of carriages, then screw the two cable nuts (fig. 45)




Fig. 45

Optional parts list

Item	Part #	Description	OHX-10
			H QTY
1	1102562008	Control connecting pin assy.	2
2	1002571011	Oil hose assy. 5/16" *140mm (2 straight)	1
3	1002571012	Cable φ9.52*10980mm	2
4	10620079	Straight fitting	1

IV. EXPLODED VIEW

OHX-10




Fig. 46

OHX-10H




Fig. 47

IX. PARTS LIST FOR OHX-10 and OHX-10H

Item	Part #	Description	OHX-10	OHX-10H
			QTY	
1	10206017	Hex Bolt M10*20	0	20
2	10209039	φ10 Washer	12	32
2A	10209022	φ10 Washer	12	52
3	10209021	Hex Nut M10	0	20
4	10209009	Cup Head Bolt M6*8	4	4
5	10209008	Safety mechanism cover assy.	2	2
6	10209010	Shaft circlip (φ10)	1	1
7	10209011	Safety mechanism pulley (P005A-1)	1	1
8	10209007	Safety Spring	2	2
9	11206002	Safety stop pin	2	2
10	10209012	φ3.2 Elastic latch	8	8
11	11209013	Power-side Safety Lock assy.	1	1
12	10206006	φ12 Washer	2	2
13	10206023A	Hex Nut M12	2	2
14	10209005	Self-locking nut (M8)	8	8
15	10209004	Rubber ringφ8*20*3	4	4
16	10209003	Hex Nut M8*25	4	4
17	071101	Power unit	1	1
18	1102561001A	Power side column assy.	1	1
19	11206020	Pulley	6	6
20	10209057B	Bronze bush	6	6
21	10209128	washerφ20	8	8
22	10209012	Elastic latchφ3.2	4	4
23	10209046	M10*35 Hex Bolt	2	2
24	11206008C	pulley support bracket assy.	2	2
25	10206009	Plastic pulley (white)	2	2
26	10209056	M10 Self-locking Nut	2	2
27	1102561006	Oli hose support bracket	2	2
27A	1061K074	Protective coil	2	2
28	1102561003A	Outer column assy.	0	2
29	1002561002	Cable	1	0
	1002571003		0	1
30	10209111	Cylinder guard coil	2	2
31	11217056	Cylinderφ50*1727	2	0
	1002576001	Cylinderφ50*1905	0	2
32	10206024	M12*25 Hex bolt	14	14
33	11206042	Control stick fixing block	2	2
34	10206011	Screw M5*12	2	2
35	10206013	Limit switch	1	1
36	10209015	Slider block	16	16
37	10209016	Carriage plastic cover	4	4
38	1102563000A	Carriage assy.	2	2
39	10209018	Rubber protection	2	2
40	10209019	M6*16 Screw	12	12
41	10520023	Shaft circlipφ38	4	4
42	11217168	Lift arm pin assy.	4	4
43	11206046A	Arm lock handle (Left)	2	2
44	10206050A	Pressure spring	4	4
45	11206046	Arm lock handle (Right)	2	2
46	10217044	Arm lock	4	4

Item	Part #	Description	OHX-10	OHX-10H
47	10206032	Shaft circlipφ25	4	4
48	10206036	Elastic shaft pinφ6*40	4	4
49	10279010	Right front arm assy.	1	1
50	1102562000 B	Top beam assy. 2	1	1
51	1102562000 A	Top beam assy. 1	1	1
52	11206025C	Control stick coupling pin	2	2
53	11206129	Control Bar L=2400mm	1	1
54	10201005	Split Pin (φ4*50)	2	2
55	11206154	Rear guard	2	2
56	10201002	M8*16 Hex bolt	4	4
57	10209034	φ8 Washer	4	4
58	10209033	φ8 Washer	4	4
59	10206156	Tool tray	2	2
60	10201046A	Rubber pad assy.	4	4
60A	10420138	Socket bolt M6*16	4	4
60B	10209134	Tray rubber mat	4	4
60C	11680030C	Rubber pad assy.	4	4
61	10279011	Rear arm assy.	2	2
62	10279009	Left front arm assy.	1	1
63	11206021	Pulley pin	2	2
64	10206019	Shaft circlipφ19	4	4
65	11206022	Pulley shaft limit cap	2	2
66	10217013	M6*20 Socket bolt	8	8
67	10420018	M6 Self-locking Nut	8	8
68	10206023	M12 Self-locking Nut	18	18
69	1102561002 A	Non-power side column assy.	1	1
70	11211013	Non-power side safety mechanism	1	1
71	11209051B	Saddle adaptor (1.5 ")	4	4
72	11209052B	Saddle adaptor (2.5 ")	4	4
73	11209053B	Saddle adaptor (5 ")	4	4
74	11209054A	Saddle adaptor bracket	2	2
75	10680003	M8*12 Hex Nut	4	4
76	10201140	Anchor bolt3/4*6-1/2	12	12
77	10201090	Level adjustment pad (1mm)	10	10
77	10620065	Level adjustment pad (2mm)	10	10
78	10209066	M16 Hex Nut	4	4
79	1002561004	Cable assy.φ9.52*9610mm	2	0
79	1002571005	Cable assy.φ9.52*10830mm	0	2
80	1002561005	Oil hose assy. (1 straight 1 bent) L=5140mm	2	0
80	1002571002	Oil hose assy. (1 straight 1 bent) L=5450mm	0	2
81	1002561001	Oil hose assy. (1 straight 1 bent) L=4155mm	1	0
81	1002571001	Oil hose assy. (1 straight 1 bent)	0	1
82	10211016	T fitting	1	1
83	10211017	90°fitting for cylinder	2	2
84	1002571009	Oil hose assy. 5/16*550mm (2 straight)	0	1
85	10620079	Straight fitting	0	1
86	1002561003	Wire cable assy. L=6980mm	1	0
86	1002571004	Wire cable assy. L=8225mm	0	1

87	1102561500	Parts box1	1	0
87	1102571500		0	1
88	1102561501	Parts box2	1	0
88	1102571501		0	1

4.1 Rear arm (10279011) explosive view




Fig 48

Item	Part #	Description	QTY	Item	Part #	Description	QTY
1	10206048	Hex bolt M10*30	6	5	11206192	Outer rear arm assy.	2
2	10209039	φ10 Spring Washer	6	6	10201149	screw 8*12	2
3	10209022	φ10 Washer	6	7	11206193	Inner rear arm assy.	2
4	11206049	Moon gear	2				

4.2 Left front arm (10279009) explosive view




Fig 49

Item	Part #	Description	QTY	Item	Part #	Description	QTY
1	10206048	Hex bolt M10*30	3	5	11206183	Outer front left arm	1
2	10209039	φ10 Spring Washer	3	6	11206189	Mid front left arm assy.	1
3	10209022	φ10 Washer	3	7	10201149	screw 8*12	2
4	11206049	Moon gear	1	8	11201049	Inner front left arm	1

4.3 Right front arm (10279010) explosive view




Fig. 50

No	Part #	Description	QTY	No	Part #	Description	QTY
1	10206048	Hex bolt M10*30	3	5	11206182	Outer front right arm	1
2	10209039	φ10 Spring Washer	3	6	11206189	Mid front right arm assy.	1
3	10209022	φ10 Washer	3	7	10201149	Screw 8*12	2
4	11206049	Moon gear	1	8	11201049	Inner front right arm	1

Cylinder (10209014/1002576001) explosive view




Fig. 51

Part list for cylinder

Item	Part #	Description	QTY	Item	Part #	Description	QTY
30-1	10209069	O-ring	2	30-8	11209076	OHX-10 piston rod	2
30-2	10209070	Bleeding Plug	2		1102576002	OHX-10H piston rod	
30-3	10209071	Support Ring	2	30-9	11209077	Piston Rod Fitting	2
30-4	10209072	Y-ring	2	30-10	10209078	Dust wing	2
30-5	10209073	O-ring	2	30-11	11209079	cover	2
30-6	11209074	Piston	2	30-12	10209080	O ring	2
				30-13	11209081	OHX-10 Cylinder assy.	2
					1102576003	OHX-10H Cylinder assy.	
30-7	10209075	O-Ring	4				

Power unit (071101) explosive view

single phase, 220V / 60HZ




Fig. 52

Part list of power unit (220V/60HZ/single phase)

Item	Part #	Description	QTY	Item	Part #	Description	QTY
1	81400180	Rubber pad	2	21	41030055	AC contractor	1
2	81400130	Starting capacitor	1	22	81400287	Motor wiring cover	1
3	81400088	Running capacitor	1	23	71111104	AMGO plate	1
4	10420148	Hex nut with washer	4	24	81400560	Throttle valve	1
5	81400066	Capacitor cover	2	25	81400266	Relief valve	1
6	81400363	Motor connecting shaft	1	26	81400284	Hex iron plug	1
7	090101	Manifold block	1	27	10720118	Elastic shaft pin	1
8	10209149	Spring washer	4	28	81400451	Release handle	1
9	81400276	Inner iron plug	1	29	10209020	Handle plastic ball	1
10	81400259	Plastic plug	1	30	81400421	Release valve nut	1
11	85090142	Hex nut	4	31	81400422	Self-locking washer	1
12	81400280	Gear pump	1	32	81400449	Valve seat(short)	1
13	10209034	washer	2	33	81400567	Release valve	1
14	81400295	Hex nut	2	34	81400566	Check valve	1
15	81400365	O-ring	1	35	81400288	Oil suction hose	1
16	10209152	Belt	1	36	81400289	Oil return hose	1
17	85090167	Magnet	1	37	81400364	Steel hoop	1
18	81400290	Filter net	1	38	81400263	Oil tank cap	1
19	81400413	Steel plate motor	1	39	81400275	Oil tank	1
20	10420070	Button switch	1				




Fig. 53

V. TEST RUN

1. Adjust synchronous cable (See Fig. 54)

Use wrench to hold the cable fitting, meanwhile use ratchet spanner to tighten the cable nut.

Make sure two cables are with the same tension so that two carriages can work synchronously.

Fit the plastic hole cover on the lifting head.

If the carriage does not Synchronize when lifting, please tighten the cable nut of lower side carriage.




Fig. 54

2. Adjust Safety Cable

Lifting the carriage and lock at the same height, strain the safety cable and then release a little, and then tighten the cable nuts. Make sure the safety device can always be worked properly.

3. Bleeding air

This hydraulic system is designed to bleeding air by loosening the bleeding plug. Lifting the carriages to about 1 meter height, and loose the bleeding plug, the air would be bled automatically, then tighten the plug after bleeding, the lift would work stably and smoothly, otherwise repeat bleeding (See Fig. 55).





Fig. 55

4. Adjust the lower speed

The speed of the descent can be adjusted if necessary. The method is to use a screw driver to adjust the Throttle valve clockwise. At this time, the descent speed becomes slower, and vice versa.



Clockwise to decrease the lowering speed

Fig. 56

Counterclockwise to increase the lowering speed

5. Test with loading

After finishing the above adjustment, test running the lift with loading. Run the lift in low position for several times first, make sure the lift can rise and lower synchronously, the Safety Device can lock and release synchronously. And then test run the lift to the top completely. If there are anything improper, repeat the above adjustment.

Hydraulic schematic




Fig.57

VI. OPERATION INSTRUCTIONS

Please read the safety tips carefully before operating the lift

To lift vehicle

1. Keep clean of site near the lift;
2. Position lift arms to the lowest position;
3. To shortest lift arms;
4. Open lift arms;
5. Position vehicle between columns;
6. Move arms to the vehicle's lifting point;

Note: The four lift arms must contact the vehicle's lifting point at the same time where manufacturers recommended

7. Push button **UP** until the lift pads contact underside of vehicle totally. Recheck to make sure vehicle is secure;

8. Continue to raise the lift slowly to the desired working height, ensuring the balance of vehicle;
9. Push lowering handle to lower lift onto the nearest safety. The vehicle is ready to repair.

To lower vehicle

1. Be sure clear of around and under the lift, only leaving operator in lift area;
2. Push button **UP** to raise the vehicle slightly, and then release the safety device, lower vehicle by pushing lowering handle.
3. Open the arms and position them to the shortest length;
4. Drive away the vehicle.
5. Turn off the power.

VII.MAINTENANCE SCHEDULE

Monthly:

1. Re-torque the anchor bolts to 150 N.M;
2. Check all connectors, bolts and pins to insure proper mounting;
3. Lubricate cable with lubricant;
4. Make a visual inspection of all hydraulic hoses/lines for possible wear or leakage;
5. Check Safety device and make sure proper condition;
6. Lubricate all Rollers and Pins with 90wt. Gear oil or equivalent;

Note: All anchor bolts should take full torque. If any of the bolts does not function for any reason, DO NOT use the lift until the bolt has been replaced.

Every six months:

1. Make a visual inspection of all moving parts for possible wear, interference or damage.
2. Check and adjust as necessary, equalizer tension of the cables to insure level lifting.
3. Check columns for plumpness.
4. Check Rubber Pads and replace as necessary.
5. Check Safety device and make sure proper condition.

VIII. TROUBLE SHOOTING

TROUBLE	CAUSE	REMEDY
Motor does not run	<ol style="list-style-type: none"> 1. Button does not work 2. Wiring connections are not in good condition 3. Motor burned out 4. AC contactor burned out 	<ol style="list-style-type: none"> 1. Replace button 2. Repair all wiring connections 3. Repair or replace motor 4. Replace AC Contactor
Motor runs but the lift is not raised	<ol style="list-style-type: none"> 1. Motor runs in reverse rotation 2. Gear Pump out of operation 3. Release Valve in damage 4. Relief Valve or Check Valve in damage 5. Low oil level 	<ol style="list-style-type: none"> 1. Reverse two power wire 2. Repair or replace 3. Repair or replace 4. Repair or replace 5. Fill tank
Lift does not stay up	<ol style="list-style-type: none"> 1. Release Valve out of work 2. Relief Valve or Check Valve leakage 3. Cylinder or Fittings leaks 	Repair or replace
Lift raises slowly	<ol style="list-style-type: none"> 1. Oil line is jammed 2. Motor running on low voltage 3. Oil mixed with air 4. Gear Pump leaks 5. Overload lifting 	<ol style="list-style-type: none"> 1. Clean the oil line 2. Check Electrical System 3. Fill tank 4. Replace Pump 5. Check load
Lift cannot lower	<ol style="list-style-type: none"> 1. Safety device are in activated 2. Release Valve in damage 3. Safety cable broken 4. Oil system is jammed 	<ol style="list-style-type: none"> 1. Release the safeties 2. Repair or replace 3. Replace 4. Clean the oil system

IX. Lift disposal.

When the car lift cannot meet the requirements for normal use and needs to be disposed, it should follow local laws and regulations.



AMGO HYDRAULIC CORPORATION

1931 Joe Rogers Blvd, Manning, South Carolina,

Zip: 29102

Tel: (803) 505-6410

Fax: (803) 505-6410

Manual no: 72128101

Revised date: 2019/10